

PHH SERIES

Size	Series	
	No Locator	with Locator
3/16	PHH-018	PHH-018L
1/4	PHH-025	PHH-025L
5/16	PHH-031	PHH-031L
3/8	PHH-037	PHH-037L
7/16	PHH-043	PHH-043L
1/2	PHH-050	PHH-050L
9/16	PHH-056	PHH-056L
5/8	PHH-062	PHH-062L
3/4	PHH-075	PHH-075L
7/8	PHH-087	PHH-087L
1	PHH-100	PHH-100L
1-1/8	PHH-112	PHH-112L
1-1/4	PHH-125	PHH-125L
1-3/8	PHH-137	PHH-137L
1-1/2	PHH-150	PHH-150L
1-3/4	PHH-175	PHH-175L
1-7/8	PHH-187	PHH-187L
2	PHH-200	PHH-200L

Automatic Pull Head R Type, Horizontal




2 - 8 Thread

PHV SERIES

Size	Series	
	No Locator	with Locator
5/16	PHV-031	PHV-031L
3/8	PHV-037	PHV-037L
5/8	PHV-062	PHV-062L
3/4	PHV-075	PHV-075L
7/8	PHV-087	PHV-087L
1	PHV-100	PHV-100L
1-1/8	PHV-112	PHV-112L
1-1/4	PHV-125	PHV-125L
1-3/8	PHV-137	PHV-137L
1-1/2	PHV-150	PHV-150L
1-3/4	PHV-175	PHV-175L
2	PHV-200	PHV-200L

Automatic Pull Head RD Type, Vertical




2 - 8 Thread

PULL HEADS ARE RENTABLE!

You can rent every size pullers we have. Keep your tool costs down, RENT IT!

PHS-8 SERIES


Semi-Automatic Pull Head 2" - 8" Thread



Size	Series	
	No Locator	with Locator
5/8	PHS-8-062	PHS-8-062L
3/4	PHS-8-075	PHS-8-075L
7/8	PHS-8-087	PHS-8-087L
1	PHS-8-100	PHS-8-100L

PHS-12 SERIES

Semi-Automatic Pull Head 1-3/8" - 12 Thread



Size	Series	
	No Locator	with Locator
3/16	PHS-12-018	PHS-12-018L
7/32	PHS-12-021	PHS-12-021L
1/4	PHS-12-025	PHS-12-025L
5/16	PHS-12-031	PHS-12-031L
3/8	PHS-12-037	PHS-12-037L
1/2	PHS-12-050	PHS-12-050L

JAWS - SPRINGS - ETC.

Replacement parts available